

B.& K. BAUMGÄRTEL GmbH

Zeitzer Str. 60/64, D-07552 Gera

Tel. +49(0)365 5512590

Fax +49(0)365 4200135

Email: baumgartel@t-online.de

Online Shop: www.pianoteile-baumgaertel.de



Operating Instructions

TRANSkip Raiser Art.-Nr. 31717

The Transkip-Grand Piano Lifter is used to lift the piano to remove one leg.



Safety Tips:

The instrument must be secured to prevent rolling!. Do not work underneath the raised piano.

Adjust the lifting plate so that it is 2 cm higher than the underside of the key bed. (Fig. 1)

Tilt the lifter to a maximum of 15° , position it under the piano and lift the instrument by pushing down on the lever arm until the arm comes to lay on the floor. (Fig. 2)

Important: Do not tilt the lifter more than 15° because the movement of the plate's ball and socket joint is limited to 15° . (Fig. 3)



- Fig. 1-



Fig. 2: **Correct!**



Fig. 3: **Wrong !**