



DESIGNS AND MODELS

| Art.-No. | Articles | Qty. | Unit |
|-----------------|---|------|------|
| | <i>COVERS for UPRIGHT and GRAND PIANOS, HARPSICHORD and other instruments</i> | | |
| 74950 | Samples of the different materials - imitation leather, felt, canvas, cloth and polyamide can be found in our samples brochure Detailed information about the covers can be found in our cover information brochure | | |
| 75000-750392 | Covers from imitation leather, inside with coated felt - Colour black/black B1 | | |
| 75050-750765 | Covers from imitation leather, inside with sewed felt - Different colours - Imitation leather: black B2, white B3, light brown B4, middle brown B5, dark brown B6, dark green B6a, claret B6 b, blue B6c - Felt: red B7, blue B8, green B9, brown B10, black B11, claret B18 | | |
| 75150-75169 | Covers from cloth, very light completion with closed back - black B19 | | |
| 7517001-7517020 | Covers from Polyamide cloth, black, with 5 mm foam padding, B20 sewed felt inside, different colours - Felt: red B7, blue B8, green B9, brown B10, black B11, claret B18 | | |
| 75200-752256 | Covers from canvas, hardwearing, strong canvas, inside with sewed felt - Different colours : grey-green B16, claret B16a, blue B16b - Felt: red B7, blue B8, green B9, brown B10, black B11, claret B18. For completion with canvas B16c (black) and very strong canvas B17 (naturel-cream), see extra charges Article No. 75226 + 75230 | | |
| 75009-750095 | Extra charges for covers for upright and grand pianos | | |
| 75010-75017 | Extra charges for covers for upright pianos | | |
| 750395-750431 | Extra charges for covers for grand pianos | | |
| 75226-75235 | Extra charges for covers for harpsichord | | |
| 3178601-3178606 | UNIVERSAL COVERS FOR TRANSPORT and PROTECTION for UPRIGHT and GRAND PIANOS + CARRY CASES for lyres and legs COVERS Discount: from 3 same covers 3% discount | | |
| | IMITATION LEATHER, inside with COATED FELT - Colour black/black B1 | | |
| 75000 | Upright piano cover 75000 up to 100 cm imitation leather / coated felt B1 | | pc. |
| 75002 | Upright piano cover 75000 up to 110 cm imitation leather / coated felt B1 | | pc. |
| 75003 | Upright piano cover 75000 up to 120 cm imitation leather / coated felt B1 | | pc. |
| 75004 | Upright piano cover 75000 up to 130 cm imitation leather / coated felt B1 | | pc. |
| 75005 | Upright piano cover 75000 up to 140 cm imitation leather / coated felt B1 | | pc. |
| 75006 | Upright piano cover 75000 up to 150 cm imitation leather / coated felt B1 | | pc. |
| 75007 | E-Piano Cover 75000 lockable, 30 cm high, imitation leather / coated felt B1 | | pc. |
| 75008 | E-Piano Cover 75000, 30 cm high, imitation leather / coated felt B1 | | pc. |
| 75020 | Grand piano cover 75000 up to 150 cm imitation leather / coated felt B1 | | pc. |
| 75021 | Grand piano cover 75000 up to 160 cm imitation leather / coated felt B1 | | pc. |
| 75022 | Grand piano cover 75000 up to 170 cm imitation leather / coated felt B1 | | pc. |
| 75023 | Grand piano cover 75000 up to 180 cm imitation leather / coated felt B1 | | pc. |
| 75024 | Grand piano cover 75000 up to 190 cm imitation leather / coated felt B1 | | pc. |
| 75025 | Grand piano cover 75000 up to 200 cm imitation leather / coated felt B1 | | pc. |
| 75026 | Grand piano cover 75000 up to 210 cm imitation leather / coated felt B1 | | pc. |



| | | | | |
|--------|--|----|--|-----|
| 75027 | Grand piano cover 75000 up to 220 cm imitation leather / coated felt | B1 | | pc. |
| 75028 | Grand piano cover 75000 up to 230 cm imitation leather / coated felt | B1 | | pc. |
| 75029 | Grand piano cover 75000 up to 250 cm imitation leather / coated felt | B1 | | pc. |
| 75030 | Grand piano cover 75000 up to 275 cm imitation leather / coated felt | B1 | | pc. |
| 75031 | Grand piano cover 75000 up to 290 cm imitation leather / coated felt | B1 | | pc. |
| 750315 | Grand piano cover 75000 up to 295 cm imitation leather / coated felt | B1 | | pc. |
| 75032 | Harpsichord cover 75000 150 cm imitation leather / coated felt | B1 | | pc. |
| 75033 | Harpsichord cover 75000 180 cm imitation leather / coated felt | B1 | | pc. |
| 75034 | Harpsichord cover 75000 190 cm imitation leather / coated felt | B1 | | pc. |
| 75035 | Harpsichord cover 75000 200 cm imitation leather / coated felt | B1 | | pc. |
| 75036 | Harpsichord cover 75000 220 cm imitation leather / coated felt | B1 | | pc. |
| 75037 | Harpsichord cover 75000 230 cm imitation leather / coated felt | B1 | | pc. |
| 75038 | Harpsichord cover 75000 240 cm imitation leather / coated felt | B1 | | pc. |
| 75039 | Harpsichord cover 75000 250 cm imitation leather / coated felt | B1 | | pc. |
| 750391 | Harpsichord cover 75000 260 cm imitation leather / coated felt | B1 | | pc. |
| 750392 | Harpsichord cover 75000 275 cm imitation leather / coated felt | B1 | | pc. |
| | IMITATION LEATHER, inside with sewed FELT - Different colours | | | |
| 75050 | Upright piano cover 75050 up to 100 cm imitation leather + felt | | | pc. |
| 75051 | Upright piano cover 75050 up to 110 cm imitation leather + felt | | | pc. |
| 75052 | Upright piano cover 75050 up to 120 cm imitation leather + felt | | | pc. |
| 75053 | Upright piano cover 75050 up to 130 cm imitation leather + felt | | | pc. |
| 75054 | Upright piano cover 75050 up to 140 cm imitation leather + felt | | | pc. |
| 75055 | Upright piano cover 75050 up to 150 cm imitation leather + felt | | | pc. |
| 750551 | E-Piano Cover 75050, lockable, 30 cm high, imitation leather + felt | | | pc. |
| 75056 | Grand piano cover 75050 up to 150 cm imitation leather + felt | | | pc. |
| 75057 | Grand piano cover 75050 up to 160 cm imitation leather + felt | | | pc. |
| 75058 | Grand piano cover 75050 up to 170 cm imitation leather + felt | | | pc. |
| 75059 | Grand piano cover 75050 up to 180 cm imitation leather + felt | | | pc. |
| 75060 | Grand piano cover 75050 up to 190 cm imitation leather + felt | | | pc. |
| 75061 | Grand piano cover 75050 up to 200 cm imitation leather + felt | | | pc. |
| 75062 | Grand piano cover 75050 up to 210 cm imitation leather + felt | | | pc. |
| 75063 | Grand piano cover 75050 up to 220 cm imitation leather + felt | | | pc. |
| 75064 | Grand piano cover 75050 up to 230 cm imitation leather + felt | | | pc. |
| 75065 | Grand piano cover 75050 up to 250 cm imitation leather + felt | | | pc. |
| 75066 | Grand piano cover 75050 up to 275 cm imitation leather + felt | | | pc. |
| 750671 | Grand piano cover 75050 up to 290 cm imitation leather + felt | | | pc. |
| 750675 | Grand piano cover 75050 up to 295 cm imitation leather + felt | | | pc. |
| 75068 | Harpsichord cover 75050 150 cm imitation leather + felt | | | pc. |
| 75069 | Harpsichord cover 75050 180 cm imitation leather + felt | | | pc. |
| 75070 | Harpsichord cover 75050 190 cm imitation leather + felt | | | pc. |
| 75071 | Harpsichord cover 75050 200 cm imitation leather + felt | | | pc. |
| 75072 | Harpsichord cover 75050 220 cm imitation leather + felt | | | pc. |
| 75073 | Harpsichord cover 75050 230 cm imitation leather + felt | | | pc. |
| 75074 | Harpsichord cover 75050 240 cm imitation leather + felt | | | pc. |
| 75075 | Harpsichord cover 75050 250 cm imitation leather + felt | | | pc. |
| 75076 | Harpsichord cover 75050 260 cm imitation leather + felt | | | pc. |
| 750765 | Harpsichord cover 75050 275 cm imitation leather + felt | | | pc. |



| | | | | |
|---------|--|------------|--|-----|
| 75150 | CLOTH - very light completion with closed back - black | B19 | | |
| 75150 | Upright piano cover 75150 up to 100 cm cloth | B19 | | pc. |
| 75152 | Upright piano cover 75150 up to 110 cm cloth | B19 | | pc. |
| 75153 | Upright piano cover 75150 up to 120 cm cloth | B19 | | pc. |
| 75154 | Upright piano cover 75150 up to 130 cm cloth | B19 | | pc. |
| 75155 | Upright piano cover 75150 up to 140 cm cloth | B19 | | pc. |
| 75156 | Upright piano cover 75150 up to 150 cm cloth | B19 | | pc. |
| 75157 | Grand piano cover 75150 up to 150 cm cloth | B19 | | pc. |
| 75158 | Grand piano cover 75150 up to 160 cm cloth | B19 | | pc. |
| 75159 | Grand piano cover 75150 up to 170 cm cloth | B19 | | pc. |
| 75160 | Grand piano cover 75150 up to 180 cm cloth | B19 | | pc. |
| 75161 | Grand piano cover 75150 up to 190 cm cloth | B19 | | pc. |
| 75162 | Grand piano cover 75150 up to 200 cm cloth | B19 | | pc. |
| 75163 | Grand piano cover 75150 up to 210 cm cloth | B19 | | pc. |
| 75164 | Grand piano cover 75150 up to 220 cm cloth | B19 | | pc. |
| 75165 | Grand piano cover 75150 up to 230 cm cloth | B19 | | pc. |
| 75166 | Grand piano cover 75150 up to 250 cm cloth | B19 | | pc. |
| 75167 | Grand piano cover 75150 up to 275 cm cloth | B19 | | pc. |
| 75168 | Grand piano cover 75150 up to 290 cm cloth | B19 | | pc. |
| 75169 | Grand piano cover 75150 up to 295 cm cloth | B19 | | pc. |
| | POLYAMIDE CLOTH black, with 5 mm foam padding, sewed felt inside | B20 | | |
| 7517001 | Upright piano cover 7517001 up to 100 cm polyamide cloth black with 5 mm foam padding, sewed felt inside | B20 | | pc. |
| 7517002 | Upright piano cover 7517001 up to 110 cm polyamide cloth black with 5 mm foam padding, sewed felt inside | B20 | | pc. |
| 7517003 | Upright piano cover 7517001 up to 120 cm polyamide cloth black with 5 mm foam padding, sewed felt inside | B20 | | pc. |
| 7517004 | Upright piano cover 7517001 up to 130 cm polyamide cloth black with 5 mm foam padding, sewed felt inside | B20 | | pc. |
| 7517005 | Upright piano cover 7517001 up to 140 cm polyamide cloth black with 5 mm foam padding, sewed felt inside | B20 | | pc. |
| 7517006 | Upright piano cover 7517001 up to 150 cm polyamide cloth black with 5 mm foam padding, sewed felt inside | B20 | | pc. |
| 7517008 | Grand piano cover 7517001 up to 150 cm polyamide cloth black with 5 mm foam padding, sewed felt inside | B20 | | pc. |
| 7517009 | Grand piano cover 7517001 up to 160 cm polyamide cloth black with 5 mm foam padding, sewed felt inside | B20 | | pc. |
| 7517010 | Grand piano cover 7517001 up to 170 cm polyamide cloth black with 5 mm foam padding, sewed felt inside | B20 | | pc. |
| 7517011 | Grand piano cover 7517001 up to 180 cm polyamide cloth black with 5 mm foam padding, sewed felt inside | B20 | | pc. |
| 7517012 | Grand piano cover 7517001 up to 190 cm polyamide cloth black with 5 mm foam padding, sewed felt inside | B20 | | pc. |
| 7517013 | Grand piano cover 7517001 up to 200 cm polyamide cloth black with 5 mm foam padding, sewed felt inside | B20 | | pc. |
| 7517014 | Grand piano cover 7517001 up to 210 cm polyamide cloth black with 5 mm foam padding, sewed felt inside | B20 | | pc. |
| 7517015 | Grand piano cover 7517001 up to 220 cm polyamide cloth black with 5 mm foam padding, sewed felt inside | B20 | | pc. |
| 7517016 | Grand piano cover 7517001 up to 230 cm polyamide cloth black with 5 mm foam padding, sewed felt inside | B20 | | pc. |
| 7517017 | Grand piano cover 7517001 up to 250 cm polyamide cloth black with 5 mm foam padding, sewed felt inside | B20 | | pc. |



| | | | | |
|---------|---|-------------|------|------|
| 7517018 | Grand piano cover 7517001 up to 275 cm polyamide cloth black with 5 mm foam padding, sewed felt inside | B20 | | pc. |
| 7517019 | Grand piano cover 7517001 up to 290 cm polyamide cloth black with 5 mm foam padding, sewed felt inside | B20 | | pc. |
| 7517020 | Grand piano cover 7517001 up to 295 cm polyamide cloth black with 5 mm foam padding, sewed felt inside | B20 | | pc. |
| | CANVAS - hardwearing, strong canvas B16/B16a/B16b, inside with sewed FELT - Different colours. | | | |
| | For completion with canvas B16c (black) and very strong canvas B17 (naturel-cream), see extra charges Article No. 75226 + 75230 | | | |
| 75200 | Upright piano cover 75200 up to 100 cm canvas + felt | B16/16a/16b | | pc. |
| 75201 | Upright piano cover 75200 up to 110 cm canvas + felt | B16/16a/16b | | pc. |
| 75202 | Upright piano cover 75200 up to 120 cm canvas + felt | B16/16a/16b | | pc. |
| 75203 | Upright piano cover 75200 up to 130 cm canvas + felt | B16/16a/16b | | pc. |
| 75204 | Upright piano cover 75200 up to 140 cm canvas + felt | B16/16a/16b | | pc. |
| 75205 | Upright piano cover 75200 up to 150 cm canvas + felt | B16/16a/16b | | pc. |
| 752051 | E-Piano cover 75200 lockable, short canvas + felt, 30 cm high | B16/16a/16b | | pc. |
| 75206 | Grand piano cover 75200 up to 150 cm canvas + felt | B16/16a/16b | | pc. |
| 75207 | Grand piano cover 75200 up to 170 cm canvas + felt | B16/16a/16b | | pc. |
| 75208 | Grand piano cover 75200 up to 160 cm canvas + felt | B16/16a/16b | | pc. |
| 75209 | Grand piano cover 75200 up to 180 cm canvas + felt | B16/16a/16b | | pc. |
| 75210 | Grand piano cover 75200 up to 190 cm canvas + felt | B16/16a/16b | | pc. |
| 75211 | Grand piano cover 75200 up to 200 cm canvas + felt | B16/16a/16b | | pc. |
| 75212 | Grand piano cover 75200 up to 210 cm canvas + felt | B16/16a/16b | | pc. |
| 75213 | Grand piano cover 75200 up to 220 cm canvas + felt | B16/16a/16b | | pc. |
| 75214 | Grand piano cover 75200 up to 230 cm canvas + felt | B16/16a/16b | | pc. |
| 75215 | Grand piano cover 75200 up to 250 cm canvas + felt | B16/16a/16b | | pc. |
| 75216 | Grand piano cover 75200 up to 275 cm canvas + felt | B16/16a/16b | | pc. |
| 75217 | Grand piano cover 75200 up to 290 cm canvas + felt | B16/16a/16b | | pc. |
| 752175 | Grand piano cover 75200 up to 295 cm canvas + felt | B16/16a/16b | | pc. |
| 75218 | Harpsichord cover 75200 150 cm canvas + felt | B16/16a/16b | | pc. |
| 75219 | Harpsichord cover 75200 180 cm canvas + felt | B16/16a/16b | | pc. |
| 75220 | Harpsichord cover 75200 190 cm canvas + felt | B16/16a/16b | | pc. |
| 75221 | Harpsichord cover 75200 200 cm canvas + felt | B16/16a/16b | | pc. |
| 75222 | Harpsichord cover 75200 220 cm canvas + felt | B16/16a/16b | | pc. |
| 75223 | Harpsichord cover 75200 230 cm canvas + felt | B16/16a/16b | | pc. |
| 75224 | Harpsichord cover 75200 240 cm canvas + felt | B16/16a/16b | | pc. |
| 75225 | Harpsichord cover 75200 250 cm canvas + felt | B16/16a/16b | | pc. |
| 752255 | Harpsichord cover 75200 260 cm canvas + felt | B16/16a/16b | | pc. |
| 752256 | Harpsichord cover 75200 275 cm canvas + felt | B16/16a/16b | | pc. |
| | EXTRA CHARGES | | | |
| 75226 | Extra charge for EXTRA STRONG CANVES, water repellent B17 | | +25% | |
| 75019 | Extra charge for black canvas | B16c | +15% | |
| | Extra charge for covers with company name + logo - printing or embroidery on request | | | |
| 75009 | Extra charge for strengthened corners outside piano, for upright and grand pianos | | | |
| 750395 | Extra charge for strengthened corners inside piano, for upright and grand pianos | | | |
| 75010 | Extra charge for upright piano cover with closed back | | +25% | |
| 75011 | Price reduction for shortened form of upright piano cover | | -20% | |
| 75012 | Extra charge for lockable upright piano cover/short, closed back | | +20% | |
| 75013 | Extra charge for lockable upright piano cover, closed back | | +45% | |
| 75014 | Extra charge for upright piano cover with fleece padding 20 mm | | +50% | |
| 75015 | Extra charge for cover with 1 zip middle front, upright and grand pianos | | | pc. |
| 750151 | Extra charge for cover with 2 zips front, upright and grand pianos | | | pair |



| | | | |
|--|--|--------|------|
| 75016 | Extra charge for upright piano cover with leaving open for handle, back | | pair |
| 750161 | Extra charge for upright piano cover with leaving open for handle, lateral | | pair |
| 75017 | Extra charge for upright piano cover with leavings for cover bows | | pair |
| 75040 | Extra charge for grand piano cover with cape until floor | +40% | |
| 75041 | Extra charge for grand piano cover with 10 cm lengthened cape | +5% | |
| 75042 | Extra charge for lockable grand piano cover | +20% | |
| 750421 | Extra charge for grand piano cover, lengthened cape with loops and rope | +20% | |
| 75043 | Extra charge for grand piano cover with 20 mm fleece padding | +50% | |
| 75045 | Extra charge for grand piano cover with 40 mm fleece padding | +75% | |
| 75226 | Extra charge for EXTRA STRONG CANVES, water repellent B17 | +25% | |
| 75230 | Extra charge for closed harpsichord cover with zip without loops (please order art. 75235 if you like to have loops) | +40% | |
| 75231 | Extra charge for closed harpsichord cover with removable zip | +50% | |
| 75232 | Extra charge for harpsichord cover, lengthened cape with loops and rope | +20% | |
| 75233 | Extra charge for harpsichord cover with 10 cm lengthened cape | +5% | |
| 75234 | Extra charge for harpsichord cover with fleece padding 20 mm | +50% | |
| 75235 | Extra charge for harpsichord cover with 2 pairs of loops | | pc. |
| TRANSPORT COVERS for GRAND PIANO to model specifications | | | |
| 3178510 | Transport cover for grand piano, canvas B16 padded, loops + rope, length 150 cm | | pc. |
| 3178511 | Transport cover for grand piano, canvas B16 padded, loops + rope, length 160 cm | | pc. |
| 3178512 | Transport cover for grand piano, canvas B16 padded, loops + rope, length 170 cm | | pc. |
| 3178513 | Transport cover for grand piano, canvas B16 padded, loops + rope, length 180 cm | | pc. |
| 3178514 | Transport cover for grand piano, canvas B16 padded, loops + rope, length 190 cm | | pc. |
| 3178515 | Transport cover for grand piano, canvas B16 padded, loops + rope, length 200 cm | | pc. |
| 3178516 | Transport cover for grand piano, canvas B16 padded, loops + rope, length 210 cm | | pc. |
| 3178517 | Transport cover for grand piano, canvas B16 padded, loops + rope, length 220 cm | | pc. |
| 3178518 | Transport cover for grand piano, canvas B16 padded, loops + rope, length 230 cm | | pc. |
| 3178519 | Transport cover for grand piano, canvas B16 padded, loops + rope, length 240 cm | | pc. |
| 3178520 | Transport cover for grand piano, canvas B16 padded, loops + rope, length 250 cm | | pc. |
| 3178521 | Transport cover for grand piano, canvas B16 padded, loops + rope, length 275 cm | | pc. |
| 3178522 | Transport cover for grand piano, canvas B16 padded, loops + rope, length 290 cm | | pc. |
| 3178523 | Transport cover for grand piano, canvas B16 padded, loops + rope, length 295 cm | | pc. |
| UNIVERSAL TRANSPORT and PROTECTION COVERS for UPRIGHT and GRAND PIANOS + CARRY CASES for lyres and legs | | | |
| 3178601 | Universal transport cover for upright piano, canvas B16 with padding, A = 72 cm, B = 60 cm, C = 30 cm, width L = 151 cm, height H = 100 cm | 100 cm | pc. |
| 3178602 | Universal transport cover for upright piano, canvas B16 with padding, A = 80 cm, B = 61 cm, C = 34 cm, width L = 151 cm, height H = 120 cm | 120 cm | pc. |
| 3178603 | Universal transport, protection and covering cover for upright piano, from strong fibre fleece, cream, about 4-5 mm thick, height 120 cm | 120 cm | pc. |
| 3178604 | Universal transport cover for grand piano, canvas B16 with padding, loops + rope, width 152 cm, length 180 cm | 180 cm | pc. |
| 31786045 | Universal transport cover for grand piano, canvas B16 with padding, loops + rope, width 155 cm, length 200 cm | 200 cm | pc. |
| 3178605 | Universal transport cover for grand piano, canvas B16 with padding, loops + rope, width 160 cm, length 220 cm | 220 cm | pc. |



| | | | |
|----------|---|--------|-----|
| 31786055 | Universal transport cover for grand piano, canvas B16 with padding, loops + rope, width 160 cm, length 230 cm | 230 cm | pc. |
| 31786056 | Universal transport cover for grand piano, canvas B16 with padding, loops + rope, width 162 cm, length 275 cm | 275 cm | pc. |
| 3178606 | Universal transport cover for grand piano, canvas B16 with padding, loops + rope, width 162 cm, length 290 cm | 290 cm | pc. |
| 3178610 | Transport bag for 3 Grand legs and transport bag for Grand lyre, made of polyester-nylon, with strong padding and transport handles, black, for legs with capitals (Grand console) with width up to 14 cm | | set |
| 3178704 | Carry case for lyre, canvas B16 with strong padding from polyamide cloth with 5 mm foam padding | | pc. |
| 3178714 | Carry case for Grand Piano legs, canvas B16 with strong padding from polyamide cloth with 5 mm foam padding | | pc. |